ThinkSpeak Platform

ThingSpeak is an Internet of Things (IoT) platform and analytics service that allows users to collect, analyze, visualize, and act on data from sensors or other devices in the cloud. It provides instant visualizations of live data streams, and with the ability to execute MATLAB code, users can perform online analysis and processing of the data as it comes in. ThingSpeak is widely used for projects involving data logging, real-time data visualization, analysis, and is often utilized for prototyping and proof of concept IoT systems requiring analytics.

ThingSpeak Key Features

ThingSpeak allows you to aggregate, visualize and analyze live data streams in the cloud. Some of the key capabilities of ThingSpeak include the ability to:


- Easily configure devices to send data to ThingSpeak using popular IoT protocols.
- Send sensor data privately to the cloud.
- Visualize your sensor data in real-time.
- Aggregate data on-demand from third-party sources.
- Use the power of MATLAB to make sense of your IoT data.
- Run your IoT analytics automatically based on schedules or events.
- Prototype and build IoT systems without setting up servers or developing web software.
- Automatically act on your data and communicate using third-party services like Twitter.

How we	can เ	used ⁻	Thinks	peak	platform
--------	-------	-------------------	---------------	------	----------

How we can used Thinkspeak platform:

1. First thing in Thinkspeak platform: Creating Channals

to send and retrieve data sensor to and from the channel



There is our channal that we created it and will use it in our project

Every channal from there channal have same settings like

Channel Name: Enter a unique name for the ThingSpeak channel

Description: Enter a description of the ThingSpeak channel.

Field#: Check the box to enable the field, and enter a field name. Each ThingSpeak channel can have up to 8 fields.

Tags: Enter keywords that identify the channel. Separate tags with commas.

Link to GitHub: If you store your ThingSpeak code on GitHub®, specify the GitHub repository URL.You now see these tabs:



Private View: This tab displays information about your channel that only you can see.


Public View: If you choose to make your channel publicly available, use this tab to display selected fields and channel visualizations.

Channel Settings: This tab shows all the channel options you set at creation. You can edit, clear, or delete the channel from this tab.

Sharing: This tab shows channel sharing options. You can set a channel as private, shared with everyone (public), or shared with specific users.

API Keys: This tab displays your channel API keys. Use the keys to read from and write to your channel.


Data Import/Export: This tab enables you to import and export channel data.




Channals

- 1. Smart Agriculture: This Channel will store sensors data like Moisture, Temperature, Humidity, Flame, Rain, Tank
- 2. Plant Data: This Channel will store plant data user will choose like Moisture, Temperature, Humidity
- 3. Smart Agriculture Mode: This Channel used to handle system mode to switch manual mode to auto mode and have one Field is Mode
- Farm Status: This Channel use to monitor Farm status like pump, Roof


2. Second thing in Thinkspeak platform: ThinkSpeak Apps





1- MATLAB Analysis: Explore data collected in a channel or scraped from a website ,Find and remove bad data ,Convert data to different units , Calculate new data ,Build data models




2- TimeControl: Use the TimeControl app to trigger an action at a specified time. You can set up TimeControl to run MATLAB® code, send ThingTweet statuses, add new TalkBack commands, or send ThingHTTP requests.








3- React: React works with <u>ThingHTTP</u>, <u>ThingTweet</u>, and <u>MATLAB Analysis</u> apps to perform actions when channel data meets a certain condition. For example, you can have a mobile app report your latitude and longitude to a ThingSpeak channel. When your position is within a certain distance of your house, have ThingHTTP turn on your living room lights.




React Settings


- **React Name**: Enter a unique name for your React.
- Condition Type: Select a condition type corresponding with your data.
 A channel can hold numeric sensor data, text, strings, status updates, or geographic location information.
- Test Frequency: Choose whether to test your condition every time data enters the channel or on a periodic basis.
- **Condition**: Select a channel, a field and the condition for your React.
- Action: Select ThingTweet, ThingHTTP, or MATLAB Analysis to run when the condition is met.
- Options: Select when the React runs.




4- TalkBack:




5- ThingHTTP: ThingHTTP enables communication among devices, websites, and web services without having to implement the protocol on the device level. You specify actions in ThingHTTP, which you trigger using other ThingSpeak apps such as TweetControl, TimeControl, and React.



Explain Our Code



General Data (Channels IDs & Channels API & Talkback)



Function To Check Moisture

```
function CheckMoisture
(soilMoisture,plantMoisture,TalkBack_apikey,url)
% Check Conditions for Moisture and handle potential
webwrite errors
if isnan(soilMoisture)
    disp(["Moisture sensor is ",soilMoisture]);
elseif isnan(plantMoisture)
    disp(["plant Moisture is ",plantMoisture]);
else
    try
        if soilMoisture >= plantMoisture
        response = webwrite(url, 'api_key',
TalkBack_apikey, 'command_string', 'TURN_ON_PUMP');
        disp("True ON PUMP");
        else
        response = webwrite(url, 'api_key',
TalkBack apikey, 'command string', 'TURN OFF PUMP');
        disp("True OFF PUMP");
        end
        % Display the response from the web service
        disp("Response:");
        disp(response);
    catch ME
        % Handle errors in the webwrite function
        disp('An error occurred:');
        disp(ME.message);
    end
end
```

This function use to check if a Soil Misture is greater than or equal to PlantMoisture and if this condition is True the PUMP will OPEN A command to turn on the water pump (TURN ON PUMP) is sent using webwrite

Else the PUMP will CLOSE The response from the web service is displayed.

This function take

(soilMoisture,plantMoisture,TalkBack_apikey,url)

As prameters and display soilMoisture, plantMoisture

TalkBack_apikey: The API key for authorization with the web service.

url: The URL of the web service to send commands to

isnan (soilMoisture): Checks if the
soilMoisture value is NaN (Not a Number),
indicating a sensor error or missing data.

catch ME: Catches any errors that occur during the execution of the try block.

Function To Check Raining

```
function
CheckRain(RainSensor, Moisture, plantMoisture, TalkBack ap
ikey,url)
if isnan(RainSensor)
    disp(["Rain Sensor is ",soilMoisture]);
elseif isnan(plantMoisture)
    disp(["plant Moisture is ",plantMoisture]);
else
    % Check if it is raining
    if RainSensor == 0 % RainSensor = 0 --> Raining
        % Check if the soil needs irrigation
        try
            if Moisture >= plantMoisture
                response = webwrite(url, 'api_key',
TalkBack_apikey, 'command_string', 'TURN_ON_ROOF');
                disp("open Roof");
            else
                response = webwrite(url, 'api_key',
TalkBack_apikey, 'command_string', 'TURN_OFF_ROOF');
                disp("close Roof");
            % Display the response from the web service
            disp("Response:");
            disp(response);
        catch ME
            % Handle errors in the webwrite function
            disp('An error occurred:');
            disp(ME.message);
        end
    else
        disp("It is not raining, no action taken.");
    end
end
end
```

This function use to check **Raining**

RainSensor == 0: Checks if the rain sensor indicates that it is raining (assuming 0 means rain).

The second condition if it raining

Moisture >= plantMoisture: Checks if the soil moisture is above the threshold needed by the plant.

If it is raining and the soil needs irrigation (moisture level is above or equal to the threshold), it sends a command to open the roof (TURN_ON_ROOF) using webwrite.

If the soil does not need irrigation, it sends a command to close the roof (TURN_OFF_ROOF) using webwrite.

If it is not raining (RainSensor is not 0), it simply displays a message indicating no action is taken.

This function take

(RainSensor, Moisture, plant Moisture, Talk Back_apike, url) As prameters

and display soilMoisture if

isnan(RainSensor): Checks if the RainSensor value is NaN (Not a Number)

and display plantMoisture if

isnan(plantMoisture): Checks if the plantMoisture value is NaN (Not a Number)

TalkBack_apikey: The API key for authorization with the web service.

url: The URL of the web service to send commands to

catch ME: Catches any errors that occur during the execution of the try block.

Function To Check Temperature

```
function
CheckTemperature(Temperature, Humidity, plantTemperature
,plantHumidity,TalkBack apikey,url)
    % Check temperature and humidity conditions
if isnan(Temperature) || isnan(Humidity)
disp(["Temperature & Humidity sensor is
",Temperature]);
elseif isnan(plantTemperature) || isnan(plantHumidity)
    disp(["plant Temperature is ",plantTemperature]);
    disp(["plant Humidity is ",plantHumidity]);
else
    try
        if Temperature >= plantTemperature
            response = webwrite(url, 'api_key',
TalkBack_apikey, 'command_string', 'close Roof');
            disp("close Roof");
        elseif Temperature <= plantTemperature</pre>
            if RainSensor == 1 % Not Raining
                response = webwrite(url, 'api key',
TalkBack_apikey, 'command_string', 'open Roof');
                disp("open Roof");
            else
                response = 'No action taken because it
is raining.';
            end
        else
            response = 'No action taken.';
        end
        % Display the response from the web service or
the custom message
        disp("Response:");
        disp(response);
    catch ME
        % Handle errors in the webwrite function
        disp('An error occurred:');
        disp(ME.message);
    end
end
end
```

This function use to check **Temperature**

If the temperature is greater than or equal to the plant's required temperature (Temperature >= plantTemperature), it sends a command to close the roof (close Roof) using webwrite.

If the temperature is less than or equal to the plant's required temperature (Temperature <= plantTemperature), it checks the rain condition.

If RainSensor == 1 (assuming 1 means not raining), it sends a command to open the roof (open Roof) using webwrite.

If it is raining (RainSensor != 1), it sets the response to "No action taken because it is raining."

If neither condition is met, it sets the response to "No action taken."

This function take

(Temperature, Humidity, plantTemperature, plantHumidity, TalkBack _apikey, url)
As prameters

and display Temperature if

isnan(Temperature) || isnan(Humidity):Checks if the Temperature and Humidity value is NaN (Not a Number)

and display plantTemperature and plantHumidity if

isnan(plantTemperature) || isnan(plantHumidity): Checks if the plantTemperature and plantHumidity value is NaN (Not a Number)

TalkBack_apikey: The API key for authorization with the web service.

url: The URL of the web service to send commands to

catch ME: Catches any errors that occur during the execution of the try block.

Function To Check Tank Level

```
function MonitorTankLevel(TankData,alertURL,options)
% Tank full --> 0
if isnan(TankData)
     disp(["Tank Sensors is ",TankData]);
else
   if TankData == 1 % empty --> 1
        alertBody = 'Tank Is Empty';
        alertSubject = 'Tank Status Alert: Empty';
        disp('Tank is empty');
        % Send alert
        try
            response = webwrite(alertURL, "body",
alertBody, "subject", alertSubject, options);
            disp('Alert sent successfully.');
            disp("Response:");
            disp(response);
        catch ME
            % Handle errors in the webwrite function
            disp('Failed to send alert:');
            disp(ME.message);
        end
   elseif TankData == 0 % Full --> 0
       disp('Tank is not Full.');
   end
end
end
```

This function use to check **Tank Level**

This function take (TankData,alertURL,options) As prameters

If TankData == 1, it indicates the tank is empty

The function sets the alert body and subject messages to indicate that the tank is empty, It then displays a message "Tank is empty".

If TankData == 0, it indicates the tank is full

It displays a message "Tank is Full ".

The function attempts to send an alert using webwrite with the alertURL, alertBody, alertSubject, and options.

If the alert is sent successfully, it displays the response from the web service.

If an error occurs during the webwrite function, it catches the exception and displays an error message.

and display TankData if

isnan(TankData):Checks if the TankData value is NaN (Not a Number)

 $\boldsymbol{\mathsf{catch}}\;\boldsymbol{\mathsf{ME}}\xspace$ Catches any errors that occur during the

Function To CheckFlameSensor

```
function MonitorFlameSensor(FlameData, alertURL, options)
if isnan(FlameData)
    disp(["Flame Sensors is ",FlameData])
else
  % Check if fire is detected
    if FlameData == 1 % fire detected
        % Define the alert message
        alert_body = 'There is a fire';
        alert_subject = 'ThingSpeak Alert email';
        disp('Fire detected! Sending alert...');
        try
            % Send the alert
            response = webwrite(alertURL, "body",
alert_body, "subject", alert_subject, options);
            disp('Alert sent successfully.');
            disp("Response:");
            disp(response);
        catch ME
            % Handle errors in the webwrite function
            disp('An error occurred while sending the
alert:');
            disp(ME.message);
        end
    else
        disp('No fire detected.');
    end
end
end
```

This function use to check **FlameSensor**

This function take (FlameData,alertURL,options)
As prameters

If FlameData == 1, it indicates that a fire has been detected.

The function sets the alert body and subject messages to indicate the presence of fire.

It then displays a message "Fire detected! Sending alert...".

If FlameData == 0, it indicates that no fire has been detected.

It displays a message "No fire detected.".

The function attempts to send an alert using webwrite with the alertURL, alertBody, alertSubject, and options.

If the alert is sent successfully, it displays the response from the web service.

If an error occurs during the webwrite function, it catches the exception and displays an error message.

and display FlameData if

isnan(FlameData): Checks if the FlameData value is NaN (Not a Number)

catch ME: Catches any errors that occur during the execution of the try block.

Check System Auto or Manual

```
systemMode = thingSpeakRead(systemChannelID,
'Fields', 1, ReadKey=systemReadAPI);
% Auto = 1 , manual = 0
if systemMode == 1
```

The thingSpeakRead function returns the value of field 1 from the specified channel, storing it in the variable systemMode.

if systemMode == 1: Checks if the systemMode value is 1, indicating that the system is in automatic mode. If true, the code within the if block will execute.